

FIG. 1




FIG. 2



Two Download Setup Code Database-Reference  
The (A) View Go Previous Page

Back Forward Home Search Helpscope Print Security Stop

Page 02

22Remote.com

Engine 5 Setup Code Database

Instructions Download Selections Requirements and Notices

### Instructions for Download

- Select the device(s) from below and click on the brand name(s) for your download.
- Please monitor the % full gauge on the left hand side of your browser.
- If % full exceeds 100%, please download some devices and check the percentages again. To start over with your device selection click the "Clear All" button.
- If the brand name is listed more than once and has numbers after the name, please try the first listing of the brand name you want. If it doesn't work for your device, try the second one, and so on.
- Click the "Next" button to confirm your selection(s) and proceed with upgrading your remote control.

### Available Devices/Brands for downloading:

Device	Brand
Satellite Receivers	Select Brand: 46
TVs	Select Brand: 48
VCRs	Select Brand: 42
CD Players	Select Brand: 42
Audio Amplifiers	Select Brand: 42
Audio Amp/Tuners	Select Brand: 42

Next Clear All

50

Microsoft Office 2000

Selection screen (part 1)

46




FIG. 4b

**File Download Setup Data Dictionary - Message**

File Edit View Go Window Help

---

Back Forward Refresh Home Search Network Print Security Stop

---

Page 50/50

\* If the brand name is listed more than once and has numbers after the name, please try the first listing of the brand name you want. If it doesn't work for your device, try the second one, and so on.

\* Click the "Next" button to confirm you understand(s) and proceed with upgrading your remote control.

### Available Devices/Brands for downloading:

Device	Brand
Satellite Receivers	Select Brand-----
Tvs	Rang & Rufus-----
VCRs	Fisher-----
CD Players	Select Brand-----
Audio Amplifiers	Realistic-----
Audio Amp/Tuners	Select Brand-----
Macintoshes Audio	Select Brand-----
Video Accessories	Select Brand-----
Home Automations	Select Brand-----
Photographs	Select Brand-----
Cable Converters	Select Brand-----

Next  
 Clear all

**42**

### Requirements and Notices:

- \* Sound card and speakers are required.
- \* Browser needs Plug-in to be able to play sound file.
- \* Network 4.0 or higher or Microsoft Internet Explorer 4.0 or higher is required.
- \* Our program will ask for permission to write to your hard hard drive. Granting it permission will speed up your

Document Name

Go Back-Microsoft Outlook    Run Download Setup    XP Microsoft Word-Template

Microsoft Word-Template

உ




FIG. 5a

FIG. 5b








FIG. 7

Microsoft

File Edit View Go Window Help

Back Forward Reload Home Search Netscape Print Security Stop

Location: file:///M:/PROJECT/PATENT/UL.config/Web\_site/signin.htm

What's Related

### Welcome to the EZRemote Download Center

If you have signed in to this web site before, please click here --> [Login](#)

One Time User?

If this is your first time on our web site, please complete the form below. If you don't have the serial number for you camera, we will send you one via email. Only one serial number per product will be assigned to a user per email address.

#### About Yourself

Email Address: \*

First Name: \* MI: \*

Last Name: \*

Street 1: \*

Street 2: \*

City: \*

State/Province: Please select a state \*

Zip/Postal Code: \*

Country: United States of America \*

Home Phone (with area code): \*

Extension: \*

Payment Method: Choose Payment Method \*

Name on Credit Card: \*

Credit Card Number: \*

Expiration Date: 01/01/00 \*

Document Title

Start Welcome to the EZR... NE 2:44 AM

Payment Screen






FIG. 8








FIG. 10





FIG. 11



**മേല**

26




FIG. 14






FIG. 15




FIG. 16




FIG. 17